



Mastercycler® personal

Bedienungsanleitung · Operating Manual · Manuel d'utilisation
Istruzioni per l'uso · Manual de Instrucciones

eppendorf

Certificate

Authorized Thermal Cycler

This instrument, Serial No. _____, is an Authorized Thermal Cycler.

Its purchase price includes the up-front fee component of a license under the foreign counterparts of U.S. Patents Nos. 4,683,202, 4,683,195 and 4,965,188, owned by F. Hoffmann-La Roche Ltd, covering the Polymerase Chain Reaction ("PCR") process, to practice the PCR process for internal research and development using this instrument. The running royalty component of that license may be purchased from Applied Biosystems or obtained by purchasing Authorized Reagents. This instrument is also an Authorized Thermal Cycler for use with applications licenses available from Applied Biosystems. Its use with Authorized Reagents also provides a limited PCR license in accordance with the label rights accompanying such reagents. Purchase of this product does not itself convey to the purchaser a complete license or right to perform the PCR process. No rights are conveyed expressly, by implication or estoppel to any patents on real-time methods, including but not limited to 5' nuclease assays, or to any patent claiming a reagent or kit.

For further information on purchasing licenses, contact the Director of Licensing at Applied Biosystems, 850 Lincoln Centre Drive, Foster City, California 94404, USA.

Applied Biosystems does not guarantee the performance of this instrument.

<i>Bedienungsanleitung</i>	1
<i>Operating Manual</i>	57
<i>Mode d'emploi</i>	115
<i>Istruzioni d'impiego</i>	173
<i>Manual de Instrucciones</i>	179
<i>EG-Konformitätserklärung</i>	186
<i>EG Conformity Declaration</i>	
<i>Déclaration de conformité</i>	
<i>Dichiarazione di conformità CE</i>	
<i>Declaración de conformidad CEE</i>	

Nachdruck und Vervielfältigung – auch auszugsweise – nur mit Genehmigung.

No part of this publication may be reproduced without the prior permission of the copyright owner.

Toute reproduction, complète ou partielle et quel que soit le procédé est interdite,
sauf autorisation expresse de notre part

Ristampa e riproduzione – anche di estratti – solo con autorizzazione.

Reimpresión y copia – incluso parciales – sólo con autorización.

Copyright© 2004 by Eppendorf AG, Hamburg

Mastercycler® is a registered trademark – US Reg. No. 2,273,536 – Canadian Reg. No. TMA510572
Mastercycler® personal is protected by US-Patent No. 6,210,958

Contents

1	Introduction	59
2	Safety precautions	60
3	Installation	62
3.1	Delivery package	62
3.2	Setting up the device	62
3.3	Starting up the device	62
4	Technical description	63
4.1	Device construction	63
4.2	Keys	64
4.3	Display	65
5	Description of menus	66
5.1	Main menu	66
5.2	Start	67
5.3	FILES	67
5.3.1	Edit	67
5.3.2	Load	68
5.3.3	Standard	68
5.3.4	New	68
5.3.5	Del = Delete	68
5.4	OPT = OPTIONS	69
5.4.1	Editor	69
5.4.2	Printer	69
5.4.3	GEN ... = GENERAL	70
5.5	Lid	71
5.6	Incu = Incubate	72
6	Operation	73
6.1	Preparation	73
6.1.1	Loading the samples	73
6.1.2	Sample volume	74
6.1.3	Heated lid	74
6.1.4	Temperature-control of the block	74
6.2	Switching on the device	75
6.3	Starting a program	75
6.4	Displaying the running time of a program	76
6.5	Interrupting a program	77
6.6	Continuing an interrupted program	77
6.7	Aborting a program	78
6.8	Switching off the device	78
7	Programming	79
7.1	Command description	79
7.1.1	CNTRL	79
7.1.2	Lid	80
7.1.3	T Selection also possible using 1	80
7.1.4	HOLD Selection also possible using 2	81
7.1.5	PAUSE Selection also possible using 3	82
7.1.6	GOTO Selection also possible using 4	82
7.1.7	SOUND Selection also possible using 5	82
7.1.8	LINK Selection also possible using 6	82
7.1.9	END	82

Contents

7.2	Creating a new program	83
7.2.1	Programming	83
7.2.2	Saving a program	85
7.3	Modifying a program	86
7.4	Creating programs using an example program.	88
7.5	Deleting a program	88
7.6	Examples of programming	89
7.6.1	Using the "Pause" and "Hold" commands (Example: Hot Start PCR)	89
7.6.2	The temperature increment (Example: Touch Down PCR)	90
7.6.3	The time increment (Example: Long PCR)	91
7.6.4	Regulating the temperature-control speed (Example: RAPD-PCR).	92
7.6.5	Sample cooling and subsequent PCR	93
8	Short instructions.	94
9	Personal card	96
9.1	Safety precautions	96
9.2	Operation	96
9.3	Processing programs	97
10	Interface description	98
10.1	Printer / PC connection	98
10.2	Program transfer	101
11	Maintenance	102
12	Troubleshooting	103
12.1	Error messages	103
13	Technical data.	108
14	Ordering information	109
14 a	Ordering information for USA and Canada	111
15	Index.	113

1 Introduction

The Mastercycler® personal is a PCR device for all molecular biological and biochemical research laboratories.

Temperature control is carried out with Peltier elements, which enable extremely rapid changes in temperature of up to 3 °C per second. This allows the temperature of the samples to be controlled extremely rapidly between 4 °C and 99 °C.

A special "tube control" mode has been developed for temperature-controlling samples in various different tubes with various different filling volumes.

The thermoblock has been constructed as a universal block which can accommodate microtiter plates in the 5 x 5 format, 25 Eppendorf PCR test tubes of 0.2 ml, 16 thin-walled Eppendorf PCR test tubes of 0.5 ml or other suitable tubes – without the block having to be exchanged.

To prevent the formation of condensation, the device has a heated lid which has been perfectly tailored to suit all tubes.

The device is easy to operate, with user guidance available in the integrated display. Experiments and tests can be documented with the aid of a printer which may be connected up to the device.

The Mastercycler® personal is an authorized cycler licensed by the Perkin-Elmer Corporation.

2 Safety precautions

Before using the Mastercycler[®] personal for the first time, please read the complete operating manual. The Mastercycler[®] personal may be used only for performing PCR and related methods in a research laboratory.

It is essential to observe the following safety precautions:



Voltage:

Before plugging in, compare your power supply with the electrical requirements listed on the identification plate of the device.

The device must be plugged into a grounded socket.

Before carrying out maintenance or cleaning work or replacing the fuses, switch off the device and disconnect it from the mains supply.



Dangerous materials:

The Mastercycler[®] personal must not be used to process explosive, flammable and highly reactive substances and must not be operated in a hazardous or potentially explosive environment.

You must observe the relevant safety regulations when handling pathogenic material, radioactive substances or other substances hazardous to health.



Liquids:

Please ensure that no liquid enters the device.



Operating environment:

Please ensure that the ventilation for the device remains unblocked at all times.



Risk of injury:

The generally applicable precautionary measures should be followed when handling the device. In particular, watch out for your hands when closing the lid.



Danger of burning:

The thermoblock, the inside of the heated lid and the micro test tubes / microtiter plates can rapidly reach a temperature in excess of 50 °C. Care must therefore be taken to avoid burns!

Do not open the heated lid until the temperatures have decreased to 30 °C.

Do not use any materials (tubes, micro titer plates, sealings, foils) which are not sufficiently temperature-stable (up to 120 °C).

▼▲ **Caution!**
Hot Surface

Symbol on the thermoblock:

This symbol warns the user that the thermoblock (▼) or the inside of the lid (▲) may be hot .

Repairs may only be carried out by an authorized specialist. Only use spare parts recommended by Eppendorf.

2 Safety precautions

Transfer

If the device is passed on to someone else, please include the instruction manual.

Disposal

In case the product is to be disposed of, the relevant legal regulations are to be observed.

The disposal of electrical devices is regulated within the European Community by national regulations based on EU Directive 2002/96/EC on waste electrical and electronic equipment (WEEE).

According to these regulations, any devices supplied after 13.08.05 in the business-to-business sphere, to which this product is assigned, may no longer be disposed of in municipal or domestic waste. They are marked with the following symbol to indicate this.



As disposal regulations within the EU may vary from country to country, please contact your supplier if necessary.

3 Installation

3.1 Delivery package

The delivery package contains the following items:

- 1 Mastercycler® personal
- 1 Main power cable
- 1 Operating manual
- 1 Personal card
- 1 bag of 0.2 ml PCR test tubes (100 pieces)
- 1 bag of 0.5 ml PCR test tubes (100 pieces)

3.2 Setting up the device

When setting up the device, please ensure that enough space is available to allow the ventilation slit to remain uncovered and to allow air to flow under the device for cooling purposes. Please ensure that no objects are under the device (e.g. lab bench paper).

No special equipment is required for transporting the device. It can be lifted up and carried by being held on both sides.

Space requirements: Width: 18 cm
Depth: 35 cm
Height: 25 cm

Mains connection: 1 shockproof socket for the Mastercycler® personal.
If a printer is to be connected up, a second mains connection must be used.

The delivery packaging should be stored in a safe place to enable the device to be shipped in the event that repairs are necessary.

3.3 Starting up the device

The Mastercycler® personal is connected to the mains supply using the main power cable. Before starting up the device, please compare the power supply with the voltage requirements listed on the identification plate (see Sec. 4.1, Fig. 3).

The procedure for connecting and starting up a printer is described in Sec. 10.1.

4 Technical description

4.1 Device construction




Fig. 1: Front view

- 1 Heated lid
- 2 Locking button
- 3 Display and control panel
- 4 Personal card reader




Fig. 2: Side view

- 1 Heated lid
- 2 Thermoblock
(not visible in this picture)
- 3 Ventilation slit
- 4 PC connection socket
- 5 Printer connection socket




Fig. 3: Rear view

- 1 Ventilation slit
- 2 Main power switch
- 3 Fuses
- 4 Main power socket
- 5 Identification plate

4 Technical description




Fig. 4: Display and control panel

- 1 Programming keys
- 2 Cursor keys
- 3 Control keys
- 4 Digit entry block, decimal point and reverse sign key
- 5 Display


4.2 Keys

Programming keys

- Opt**
 - When this key is pressed, the approximate remaining run time of a program and the time of the expected end of the program appears in the display for approximately five seconds.
 - To select programming options for the "Temperature" command (ramp, increment).
- Del**
 - To delete program lines, digits or letters or to reset parameters. Holding down the key deletes not only individual letters but also a complete name.
- Sel**
 - To select a program command or to select from a list.
 - A menu item can be selected using the **Sel** key instead of the **▲** / **▼** keys.
 - The **Sel** key can also be used to select from a list and to enter the letters of program names. The direction of selection of the letters can be changed by pressing the **±** key.
- Ins**
 - To insert program lines during the creation of a program.

4 Technical description

Cursor keys



The cursor appears in the display as a dark field.

- If a menu should be selected, the cursor must be moved to that menu and the selection should then be confirmed by pressing .
- The cursor is also used to move into, or to change between, input fields. Entries do not have to be confirmed by pressing ; they are stored immediately.

Control keys



- To exit a menu or to return to the next-highest menu level.
- After a program has been started, the display of the program can be exited, e.g. in order to work in the programming level.



- To call up a menu which has been selected using the cursor.
- To confirm an entry.



- To quick-start a program from the processing level ("FILES/Edit" menu). If another program needs to be started, the "Start" menu must be used.
- To cancel or to interrupt a program.

4.3 Display

Press the main power switch on the rear of the device (Sec. 4.1, Fig. 3.2). The device name and the software version installed appear briefly in the display.


Example:

```
MASTERCYCLER
personal 5332
eppendorf
Version *.*.*
```

The main menu then appears in the display.

5 Description of menus

5.1 Main menu




A menu or a sub-menu can be called up in three different ways:

1. Select using the / keys and confirm by pressing ; a "→" appears in front of the menu.
2. Select using the key and confirm by pressing .
3. Select the menu using the internal position number (shown in brackets in the text) and confirm by pressing .

The program in the processing level can be started immediately by pressing the key. Menus are exited by pressing the key. To access the main menu, it may be necessary to press the key several times. Menus written in capital letters have additional sub-items. For ease of reference, the menu name appears on the left-hand side of the display or as a headline above the menu or as a sub-item.

Overview of the entire menu structure:



5 Description of menus


5.2 Start

Only programs can be started from the "Start" menu.

The program displayed in the processing level can be started directly by pressing the  key (1).

If a program which has been stored has to be started, it is selected with the cursor keys from the displayed list after  has been pressed (2) and confirmed by pressing .

The "Start" menu has no sub-programs.



5.3 FILES

The "FILES" menu is used to change, load, create or delete programs.



5.3.1 Edit

The "Edit" menu is used to change existing programs. The program which is to be changed may already be in the "processing level" or it is loaded into the processing level via the "Load" menu. This is applicable for programs from the internal device memory or from a personal card.

The program which has been changed can be checked by pressing the  key after the program has been saved under a new name. The processing level is not deleted when this program is saved. The program data remains stored even when the device is switched off and is overwritten only when the "New" or "Standard" sub-menu is called up.

Note: If the program which has been changed (without being saved under a new name) is started, there are then two different programs with the same name (one in the internal memory and one in the processing level).

5 Description of menus

5.3.2 Load

"Load" is used to call up a list of existing programs. These programs may be taken from the internal memory or from a personal card. The selected program is loaded into the "Edit" processing level. If the "Edit" processing level contains a program which has not been saved, a safety check appears in the display, which then enables the program to be saved.

If the user does not want to save the program, it is overwritten when the new program is loaded. As the "Edit" processing level is called up automatically, the program can be changed immediately and can then be tested for test purposes.

The procedure for loading programs from a personal card is described in Sec. 9.3.

5.3.3 Standard

An example program called "Standard" is available for creating new programs. It is not necessary to rewrite a program completely; the example program can be supplemented or changed and then saved under a new name. All programs which are in the internal memory can be used as an example program.

Following a safety check, the example program is loaded into the processing level. The process is described in more detail in Sec. 7.4.

Although the "Standard" example program cannot be deleted, it can be changed to suit individual requirements. After the changes have been made, the example program is saved under the name "Standard". To restore the original example program, the "Standard" program must be deleted in the "Del" sub-menu. When "Standard" is called up again, it is the original example program which is then loaded into the processing level.

5.3.4 New

"New" can be used to call up the processing level automatically. To create a new program, an existing program is deleted.

The essential input CNTRL BLOCK, Lid =0°, NOWAIT AUTO, end is simulated automatically and the program is given the provisional title UNNAMED.

5.3.5 Del = Delete

Programs can be deleted from the internal memory or from a personal card. After "Del" has been selected, a list of program names appears in the display. A program can be selected from this list using the cursor key and can be deleted by pressing . The program in the processing level cannot be deleted.

The procedure for deleting programs from a personal card is described in Sec. 9.3.

5 Description of menus

5.4 OPT.... = OPTIONS

The "OPT" menu can be used to define general system settings for the program editor, printer, time/date, etc.



Selection of YES/NO, ON/OFF and other settings can be carried out using the **Sel** key.

The menu is exited by pressing the **Exit** key.

5.4.1 Editor

```
-- -- Editor Mode: -- --
Show Ext. Steps: YES
```

Show Ext. Steps To display temperature options.

YES

All options (temperature increment, time increment, ramp, ramp increment) for each step appear in the display.

NO

Only the nominal temperature and the cycle time appear in the display. If the options have been defined, the command is marked with an "*" for information purposes when the program is called up. Nonetheless, the options can be called up by pressing the **Opt** key and can then be entered or displayed.

5.4.2 Printer

```
-- -- Printer Mode: -- --
Printout Editor: NO
Print Protocol: OFF
```

Entries are necessary only when a printer is connected.

Printout Editor

YES: The program in the "Edit" processing level is printed out. If "YES" has been selected, but no printer is accessible, the error message "Printer: No Response" appears in the display.

NO: Appears automatically when the program printout has finished.

Print Protocol

ON: When the program starts, the commands are printed out; during the run, every completed command is printed out together with the time.

OFF: No printout is made.

5 Description of menus

5.4.3 GEN... = GENERAL

The "GEN" menu is available to enter general settings and to test the device.

```
GEN ...      | → Clock
STANDARD    | Remote
-- /28.7°   | Sound
8:45:13     | Etc VAL
```

- Clock**
- Format: The time in the 24-(military) or 12-hour-clock format (choice of PM or AM) can be selected using the key.
- Time: To enter the current time in hours:minutes:seconds.
- Date: To enter the current date as day/month/year.
The month can be selected using the key.
- Remote**
- Baud rate: The transmission rate of 19,200, 9,600, 4,800, 2,400 or 1,200 for a PC connection can be selected using the key.
- Sound**
- KeyClick: ON: Every keyclick is confirmed by an acoustic signal.
OFF: The acoustic signal for keyclicks is switched off.
- Warnings: ON: In addition to the warning text, warnings are acknowledged by an acoustic signal.
OFF: No acoustic signal is emitted to acknowledge a warning.
- Note:** Errors are always acknowledged by an acoustic signal, irrespective of this setting.
- Etc**
- Start with: MAIN: After the device has been switched on, the main menu appears in the display.
LAST: After the device has been switched on, the most-recently used menu appears in the display.
- Auto Restart: NO: A program interrupted by a power failure is not continued.

```
PROGRAM      interrupted
Time:        Duration
Step:x       Cyc:y
Press any key!
```

- YES: Depending on the duration of a power failure, an interrupted program will automatically continue or can be manually continued or stopped.

```
PROGRAM      restarted
Time         Duration
Step:x       Cyc:y
Press any key!
```

Power failure < 3 min:

A currently running program automatically continues if power is restored within 3 minutes of the commencement of the power failure. A display indicates when,

how long and at which step the program was interrupted.

When any key is pressed, the display jumps back to the program view. If the program is to be cancelled, press the key and confirm by

.

5 Description of menus

PROGRAM	interrupted
Time	Duration
Step:x	Cyc:y
Restart:	YES/NO

Power failure > 3 min:

In the event of a longer power failure, an acoustic warning signal is given as soon as the power supply returns, and the program can be manually continued or stopped.

If the interrupted program is to be continued, select "YES" with and confirm with . Press any key to return to the program view.

If the program is to be discontinued, select "NO" with and confirm with .

VAL These programs can be used to test the device. The measurements can be documented by connecting a printer to the device. The "Validate" and "Calibrate" menus require the temperature-validation system (order no.: 5331 222.005). This system consists of a special temperature sensor and a personal card with the corresponding software. For precise information on operating the "Validate" and "Calibrate" programs, see the operating manual for the temperature-validation system.

Validate: To check the device temperature with the aid of a temperature-measuring device. This measuring device forms part of the temperature-validation system and is connected via the serial interface of the Mastercycler® personal.

Calibrate: To align the device temperature with the aid of a temperature-measuring device. This measuring device forms part of the temperature-validation system and is connected via the serial interface of the Mastercycler® personal.

5.5 Lid

The "Lid" menu in the main menu can be used to determine the temperature of the heated lid and to switch the heated lid on or off (e.g. to preheat the lid).

---	Lid Temp: ---
LidTemp:	100/20°C
Heater is Off:	

LidTemp: Nominal/actual temperature. To enter the temperature for the heated lid. The lid heating switches off when a temperature value of 0 °C is entered.

Heater is On: Lid heating is on.

Heater is Off: Lid heating is off.

When sensitive PCRs are carried out, it may be important to delay the start until the lid temperature has prevented condensation. This can be achieved by programming the "WAIT" setting, which means that the program does not start until the lid reaches the specified temperature.

In addition, the lid can also be preheated. After the device has been switched on, the "Lid" menu is selected, the desired lid temperature is entered and "Heater is On" is selected by pressing the key.

When a program starts, it is the program settings which have priority.

When a program is running, the lid heating cannot be switched on or off .

5 Description of menus

5.6 Incu = Incubate

The "Incu" menu in the main menu is used to determine the block temperature and to switch on/off the temperature control of the block (e.g. for incubation experiments or to preheat the block). The temperature of the heated lid is aligned to that of the block.

```
--- Block Temp: ---  
Temp:          37 °C/22 °C  
Heater is Off
```

Temp: Nominal/actual temperature. To enter the temperature for the thermoblock. It is possible to enter values from +4 °C to 99 °C.

Heater is On: Temperature control of the block is on.

Heater is Off: Temperature control of the block is off.

To bring the thermoblock and the heated lid to the desired temperature, select the "Incu" menu after the device has been switched on, enter the desired block temperature and select "Heater is On" using the **Sel** key.

If "Incu" is running, the "Lid" menu cannot be selected.

When a program starts, it is the program settings which have priority.

When a program is running, the temperature control of the block cannot be switched on or off.

To interrupt: If "Heater is On" is in the display, set the device to "Heater is Off" using the **Sel** key and confirm by pressing **Enter**.

Caution: If the "Incu" menu has been selected, the thermoblock and the heated lid may be hot when the tubes are inserted, which means that there is a high burns risk for the user.

6 Operation

6.1 Preparation


6.1.1 Loading the samples

The thermoblock can be loaded with three different types of tubes without needing to be exchanged. It can accommodate 25 PCR test tubes of 0.2 ml or 16 thin-walled PCR test tubes of 0.5 ml (special tube from Eppendorf) or 1 microtiter plate (5x5).


To achieve an optimal temperature transition, only sample tubes and microtiter plates with a V-shaped base should be used (see "Ordering information"). Test tubes must fit tightly into the thermoblock and should not wobble or move in any way. Tubes which are not sufficiently temperature-stable (up to approximately 120 °C) should not be used.

In general, this also applies to foils used to seal microtiter plates. However, due to the temperature-controlled lid heating, it is also possible to use foils which would melt above 100 °C. In this case, the lid heating can be set, for example, to 95 °C.


The thermoblock has 25 narrow positions for 0.2 ml test tubes and microtiter plates and 16 wide positions for 0.5 ml tubes. To enable the maximum possible number of 0.5 ml test tubes to be inserted into the thermoblock, the tubes must be positioned in rows. In addition, in order to ensure that the heated lid is closed evenly, it is strongly recommended to position a tube in each corner of the thermoblock. Loading should be carried out as follows:



25 x 0.2 ml PCR test tubes
or
microtiter plates (5x5)



16 x 0.5 ml thin-walled PCR test tubes
(special tube from Eppendorf)



8 x 0.5 ml Eppendorf Safe-Lock micro test tubes
0.5 ml tubes with wide lid, e. g. 0.5 ml Eppendorf
micro test tubes, should be loaded in a staggered way

6 Operation

6.1.2 Sample volume

Temperature control can be set to thermoblock or to sample.

The device can adapt to the actual sample quantity and test tube type via the command "CNTRL /TUBE". For maximum flexibility, the program will prompt for tube sizes and volumes when it is started.

The following sample quantities should be used:

0.2 ml test tubes or "plate": not larger than 50 μ l

0.5 ml or 0.5 ml thin-walled test tubes: not larger than 100 μ l

6.1.3 Heated lid

After the samples have been loaded, the heated lid is closed over the thermoblock and locked using the locking lever. The locking lever is moved to the right until the correct tube height has been reached. The symbols indicate the sealing positions for tubes and plates in accordance with the height for a capacity of 0.5 ml, 0.2 ml or 0.1 ml. When plates are loaded, the position "0.2 ml tube" or "Plate" must be selected accordingly.

Note: Some types of PCR plates lock into position at the 0.2 ml tube level. Do not force the locking lever when this happens.

Since the heated lid prevents the liquid from condensing in the upper part of the tube, it is not necessary to use an oil layer.

Note: Different tube types should not be loaded together as they cannot be sealed correctly by the heated lid. If it is absolutely necessary to process different tube types simultaneously in the thermoblock, an oil layer is necessary for the smaller tubes.

The lid temperature (up to 110 °C) is controlled automatically by the program. The user can decide whether the program should start immediately (NOWAIT) or whether it should start after a preset lid temperature has been attained (WAIT). If the program has to start quickly, the heated lid can be preheated using the "Lid" menu.

All tubes are easily accessible during the temperature-control procedure since the lid can be opened at any time.

Caution: To avoid the risk of burns (110 °C) caused by touching the inner surface of the lid or the thermoblock, do not open the lid while the program is running. Depending on the processing temperatures used, test tubes and microtiter plates may also be extremely hot.

6.1.4 Temperature-control of the block

To carry out incubation experiments or to speed up the start of a method, it is possible to temperature-control the thermoblock with the heated lid. The "Incu" menu is selected in the main menu, a block temperature is entered and "Heater" is set to "On".

Caution: Since the thermoblock and the heated lid can become very hot, there is a burns risk for the user when test tubes and microtiter plates are inserted.

6 Operation

6.2 Switching on the device

- Switch on the device using the main power switch on the rear of the device.

The current software version appears briefly in the display. The main menu then appears.

```
MASTERCYCLER
personal 5332
eppendorf
Version *.*.*.*
```

The program which is ready to be started appears in the processing level.

```
Main-Menu | → Start
STANDARD | FILES..
-- /25.0° | OPT ....
10:38:45 | Lid Incu
```

6.3 Starting a program

- The program in the processing level can be started immediately by pressing the  key.

To start another program,

- press .

A list of the programs appears in the display.

The cursor "→" always points to the program last used.

- Start the program by pressing  to confirm or
- Select the program name using the  or  key (Move the cursor "→" in front of the program name).

The procedure for starting programs which are stored on a personal card is described in Sec. 9.3.

- Press .

The program starts immediately after a "Testing Program".

If the program contains the "CNTRL/TUBE" command (temperature control set to sample), it is necessary to enter the tube type and the filling volume after the program has started.

```
→ STANDARD
TEST1
TEST2
```

- Select the tube type 0.2 ml, 0.5 ml (e.g. Safe-Lock), 0.5 ml thin (thin-walled tubes), plate (microtiter plate).

```
          CNTRL      TUBE
Tube: 0.2 ml
-- /45.6°
10:48:43
```

6 Operation

- Enter the filling volume and confirm by pressing .

Tube type 0.2 ml/plate: 5 to 50 μ l

Tube type 0.5 ml/thin: 5 to 100 μ l

If no entries are made for "Tube" and "Fill.Vol.", the program will not run.

"EnterTube" appears in the main menu instead of the program name and a long acoustic signal is emitted until the entry is made.

When a program is running, the command which is being processed is shown in the display.

A flashing temperature display indicates that the nominal temperature has not been attained and that heating/cooling is currently taking place.

- The display of a program can be exited at any time (e.g. to program in the "Edit" processing level) by pressing .

CNTRL	TUBE
Fill. Vol.: 20 μ l	
- - /45.6°	
10:48:43	

1	T=94.0°	0:02:00
	94.0/94.7°	0:01:02
	Lid:105°	Cyc: 1

Lid temperature or time
(when working without lid heating)
Cyc = no. of finished cycles

Nom./act. block temperature,
remaining time (time is counted down)

Program step number, Program command
in example: Temperature command (T)
with nom. temperature and length of cycle

6.4 Displaying the running time of a program

While a program is running, the approximate run time and the expected end time of the program can be shown in the display

- Press .

The key is effective only when a program run appears in the display, not in the main menu, with other menus or sub-menus.

Run Time:	1:04
Finish Time:	12:54
25/Apr/1999	11:50:12

Current time

Program end

Run time in hours:minutes

6 Operation

6.5 Interrupting a program

A program can be aborted, paused or continued at any point by pressing .

- Press .

Using the  key, select between:

Stop To abort the program
Pause To interrupt the program
Run To return to the display of the program sequence

- Using the  key, move to "Pause".
- Confirm "Program:PAUSE" by pressing .

The program is interrupted, time counting stops and the last nominal temperature is retained.

The name of the interrupted program appears in the main menu in alternation with "Paused" and the "Start" menu changes to the display "Stop".

```
STANDARD running . . .  
Program: STOP  
94.0/93.9°  
Lid: 105°
```

```
Main-Menu | → STOP!  
Paused . . . | FILES..  
94.0/93.9° | OPT ....  
10:38:45 | Lid Incu
```

6.6 Continuing an interrupted program

The name of the program appears in the display in alternation with "Paused".

- Press .

Using the  key, select between:

Stop To abort the program
Pause To interrupt the program
Resume To continue the program

- Using the  key, move to "Resume".
- Confirm "Program:RESUME" by pressing ; the program is continued.

```
STANDARD PAUSED . . .  
Program: PAUSE  
94.0/93.9°  
Lid: 105°
```

```
1 T=94.0° 0:02:00  
94.0/94.7° 0:01:02  
Lid:105° Cyc: 1
```

6 Operation

6.7 Aborting a program

A program can be aborted at any point.

Either

- Press .
 - Confirm "Program:STOP" by pressing 
- or
- by using the "→ Stop" menu from the main menu (e.g. after a method has been edited).

```
1    T=94.0°    0:02:00
94.0/94.7°    0:01:02
Lid:105°      Cyc: 1
```

```
Main-Menu | → STOP!
Running ... | FILES..
           | OPT ....
           | Lid Incu
```

- Move cursor to "Stop".
- Confirm menu "STOP!" by pressing 
- Confirm "Program:STOP" by pressing 

```
STANDARD running . . . . .
Program: STOP
94.0/93.9°
Lid: 105°
```

6.8 Switching off the device

After a program has been completed, the following appears in the display:

```
End of Program
--/25.0°
14:04:36
```

If a new program has to be started, exit the old program by pressing .

To switch off the device, move the main power switch on the rear of the device to .

7 Programming

7.1 Command description

A program contains two basic commands for controlling the temperature of the thermoblock and of the heated lid as well as six different commands for programming.

A program can contain up to 40 program lines. The commands may be repeated as desired.

Digits or letters may be entered or selections are made using the key.

When digits are entered, the message "Value out of range" appears when values are entered which are not within the given specifications. The permitted limit value is then entered automatically.

```
--- Edit UNNAMED ---  
  
CNTRL      BLOCK  
  
LID=***°  
NOWAIT     AUTO  
  
1  T=****°   **: **: **  
   +0.0°     + 0:00  
   R=3.0°/s  + 0.0°/s  
  
2  HOLD ***° ENTER  
  
3  PAUSE PRESS ENTER  
  
4  GOTO ***  REP ***  
  
5  SOUND **  
  
6  LINK *****
```

7.1.1 CNTRL

With this command is determined the type of temperature control for the block.

BLOCK The temperature is measured on the thermoblock and the nominal temperature is then set.

TUBE The software adapts the temperature of the thermoblock to the temperature of the tubes and the sample quantity. For this reason, the tube type and the filling volume must be entered immediately after the start of the program.

Tube type 0.2 ml or plate: 5 to 50 µl filling volume
 0.5 ml or 0.5 ml thin: 5 to 100 µl filling volume

7 Programming

7.1.2 Lid

To determine the temperature of the heated lid. If 0 °C is selected, the heated lid remains switched off.

Permitted values	0 to 110 °C
Entry increments	1 °C

In addition to the entry for the temperature of the heated lid, it is also possible to determine the behavior of the lid temperature at the start and at the end of a program:

At the start

NOWAIT The program is started, independent of the lid temperature.

WAIT The program is not started until the programmed lid temperature has been attained.
Note: To accelerate the start of the program, the lid may be preheated using the "Lid" menu.

At the end

FIX The lid temperature does not depend on the block temperature. The lid heating is switched off at the end of the program.

AUTO The lid temperature depends on the block temperature. If 22 °C is maintained for longer than five minutes, the lid heating switches off; this is also applicable in the case of a Hold command at temperatures < 22 °C.

The six commands for programming can be called up directly using the allotted number.

7.1.3 T Selection also possible using 1

To enter the temperature and the cycle time as well as the accompanying specific options.

The options are entered by positioning the cursor on the program line number and pressing the Opt key.

The options may be entered for every temperature command.

T=****°	***:**:**	Nominal temperature, cycle time
+ 0.0°	+ 0:00	Temperature increment, time increment
R= 3 %/s	+ 0.0 %/s	Ramp, ramp increment

T=**°** The nominal temperature is entered in degrees Celsius (°C).

Permitted values	4 to 99.0 °C
Entry increments	0.1 °C

*****:**:**** The cycle time is entered in "hours:minutes:seconds".

Permitted values	0:00:01 to 9:59:59
Entry increments	1 s

7 Programming

$\pm 0.0^\circ$ Temperature increment ($\pm^\circ\text{C}$): For each cycle, the temperature is increased or decreased by the value entered here.

Please note that the temperature cannot exceed 99°C . For example, with a temperature increment of $+0.1^\circ\text{C}$ and 25 cycles, the starting temperature cannot be greater than 96.5°C . First enter the numerical value and then the plus or minus sign.

Permitted values	0.0 to 10.0°C
Entry increments	0.1°C
Entry for temperature increase	"+"
Entry for temperature decrease	" - "

$\pm 0:00$ Time increment ($\pm\text{s}$): For each cycle, the time is extended or reduced by the value (max. 1 minute) entered here.

Entry for time extension	"+"
Entry for time reduction	" - "
Permitted values	0:00 to 1:00
Entry increments	1 s

$R = 3\%/s$ Ramp (K/s): The ramp states the speed of the heating or cooling curve of a cycle. The higher the value entered, the more rapidly the heating or cooling takes place. Most reactions require rapid heating or cooling rates, i.e. a high value. For processes in which heating or cooling should take place slowly, different values may be entered for the ramp.

Permitted values	0.3 to 3 K/s
Entry increments	0.1 K/s

$\pm 0.0\%/s$ Ramp increment ($\pm\text{s}$): For each cycle, the ramp is raised or lowered by the value entered here. Please note that the ramp cannot exceed 3 K/s, i.e. with an initial ramp entry of 0.3 and a ramp increment of 0.1, a maximum of 27 cycles is possible. First enter the numerical value and then the plus or minus sign.

Permitted values	0.0 to 1.0 K/s
Entry increments	0.1 K/s
Entry for increasing the ramp speed	"+"
Entry for decreasing the ramp speed	" - "

7.1.4 HOLD Selection also possible using 2

The program holds the temperature at the value which was entered. The program is continued or ended by pressing .

Note: A program should not begin with a HOLD command and a temperature $< 22^\circ\text{C}$ because the temperature-control for the lid will not start. If, for example, 4°C is required at the beginning of a program, HOLD should be connected to the main program via a LINK command (see Sec. 7.6, "Examples of programming").

HOLD xx ENTER

Permitted values	4 to 99°C
Entry increments	0.1°C

7 Programming

7.1.5 PAUSE Selection also possible using 3

The program is interrupted and the temperature remains at the value for the last temperature command. The program is continued by pressing .

A user-defined text may be entered instead of the preset text "PRESS ENTER".

PAUSE PRESS ENTER

Text length 0 to 11 characters

7.1.6 GOTO Selection also possible using 4

To enter data for cycle repeats. It is possible to branch to another program line number (GOTO) where the program should be continued. The number of times this should be carried out (REP) is also given.

GOTO xxx REP xxx

Permitted values
Program line number 1 to 40
Repeats 1 to 99

7.1.7 SOUND Selection also possible using 5

To emit an acoustic signal (e.g. for displaying a programmed pause or when a program is ended).

SOUND**

Permitted repeats 1 to 10 tones

7.1.8 LINK Selection also possible using 6

To link up with another program in the internal memory. Via the LINK command, the current program is ended and the selected program is started. With the aid of LINK commands, a maximum of five programs may be run in succession. The CNTRL, Lid, NOWAIT/WAIT, AUTO/FIX commands in the program head are not taken into consideration during the subsequent programs.

It is not possible to branch to programs in the processing level ("Edit") or on the personal card using LINK commands (it is possible from the personal card to programs in the internal memory).

LINK*****

Permitted number of programs 5

The name of the program to be called up must be entered (select letters using the key). If the name of the program itself is entered, the program goes into an endless loop and can only be cancelled by pressing "Stop".

7.1.9 END

END appears automatically as the last line of a program. It switches off the temperature control for the block and for the lid.

7 Programming

7.2 Creating a new program

Example for a program sequence:

Initial denaturation 95 °C for 2 minutes

20 cycles:

Denaturation 95 °C for 45 seconds

Annealing 61 °C for 45 seconds with a temperature increment of -1 °C

Elongation 72 °C for 45 seconds

Final elongation 72 °C for 2 minutes

Cooling of samples 22 °C

7.2.1 Programming

- Select the "FILES" menu using the  or  key and call up by pressing .

```
Main-Menu | → Start
STANDARD | FILES..
-- /25.0° | OPT ....
10:38:45 | Lid Incu
```

- Select the "New" menu using the  or  key and call up by pressing .

```
FILES . . | Edit
STANDARD | Load
-- /25.0° | Standard
10:38:45 | → New Del
```

CNTRL BLOCK

- Using the  key or confirm by pressing .

```
- - - Edit UNNAMED - - - -
CNTRL          BLOCK
LID=0°
NOWAIT        AUTO
```

LID=105° NOWAIT AUTO

- Enter the values and press the , ,  keys.
Change "Nowait" and "Auto" ( key)
or confirm by pressing .

```
- - - Edit UNNAMED - - - -
LID=105°
NOWAIT        AUTO
1 T=****°     **:*:*:**
```

Initial denaturation

T=95.0° 0:02:00

- Select command T (Temperature) using the  key (it may be necessary to press the key several times) and confirm by pressing .

```
- - - Edit UNNAMED - - - -
NOWAIT        AUTO
1 T=95.0°     **:*:*:**
end
```

- Enter the temperature, press the ,  keys and confirm by pressing .

7 Programming

- Enter the time (seconds:minutes:hours).

Press the , , keys and confirm by pressing

.

```
- - - Edit UNNAMED - - - -  
      NOWAIT      AUTO  
1   T=95.0°      0:02:00  
   end
```

Denaturation

T=95.0° 0:00:45

Programming: see page 26

```
- - - Edit UNNAMED - - - -  
1   T=95.0°      0:02:00  
2   T=95.0°      0:00:45  
   end
```

Annealing

T=61.0° 0:00:45

Temperature increment –1°

- Select command T and confirm by pressing .

```
- - - Edit UNNAMED - - - -  
1   T=95.0°      0:02:00  
2   T=95.0°      0:00:45  
3   T=****°      **:*:*:**
```

- Press the , keys and confirm by pressing .

- Press the , keys and confirm by pressing .

```
- - - Edit UNNAMED - - - -  
2   T=95.0°      0:00:45  
3   T=61.0°      0:00:45  
   end
```

- To enter the options for the temperature command, move to the program line number using .

- Press the key.

```
- - - Edit UNNAMED - - - -  
2   T=95.0°      0:00:45  
3   T=61.0°      0:00:45  
      +0.0°      +0:00
```

Hold down the key until the cursor is on the position which has to be changed.

Temperature increment –1°

```
- - - Edit UNNAMED - - - -  
2   T=95.0°      0:00:45  
3   T=61.0°      0:00:45  
      -1.0°      +0:00
```

- Press the , keys.

- Using , move to the next program line number. The "*" indicates that an option has been entered for this temperature.

```
- - - Edit UNNAMED - - - -  
3   *T=61.0°      0:00:45  
   end
```

7 Programming

Elongation

T=72.0° 0:00:45

Programming: see page 26

Cycle

GOTO 2 REP 19

- Select the GOTO command using the **Sel** key (it may be necessary to press the key several times). Confirm by pressing **Enter**.
- Enter the line number for the beginning of the program section which is to be repeated. Confirm by pressing **Enter**.
Enter the number of repeats (REP). Confirm by pressing **Enter**.

Note: The total number of cycles is REP + 1.

```
- - - Edit UNNAMED - - - -  
3 *T=61.0° 0:00:45  
4 T=72.0° 0:00:45  
5 GOTO*** REP***
```

Final elongation

T=72.0° 0:02:00

Programming: see page 26

```
- - - Edit UNNAMED - - - -  
4 T=72.0° 0:00:45  
5 GOTO 2 REP19  
6 T=72.0° 0:02:00
```

Cooling of samples

HOLD 22.0° ENTER

- Select the HOLD command using the **Sel** key (it may be necessary to press the key several times) and confirm by pressing **Enter**.
- Enter the temperature. Confirm by pressing **Enter**.

```
- - - Edit UNNAMED - - - -  
5 GOTO 2 REP19  
6 T=72.0° 0:02:00  
7 HOLD 22.0° ENTER
```

7.2.2 Saving a program

- Exit the menu using the **Exit** key.
- To save, press the **Enter** key; the device asks for the program name.

```
- - - Edit UNNAMED - - - -  
UNNAMED not saved  
Save: YES
```

In the case of a new program, the device suggests the name "UNNAMED".

- Confirm the name by pressing **Enter** or – if an other name is desired – delete by pressing **Del** (if the key is held down, the entire name is deleted; if the keys is pressed briefly, individual letters only are deleted).

```
- - - Edit UNNAMED - - - -  
UNNAMED not saved  
Save: YES  
ProgName: UNNAMED
```

7 Programming

- Enter the new program name.
Select letters using the **Sel** key.
Press the **▶** key to move to the next position etc.
and confirm by pressing **Enter**.

```
- - - Edit UNNAMED - - - -  
UNNAMED not saved  
Save: YES  
ProgName: Test
```

If the program is to be saved under an existing name, the question appears:

- "Overwrite:YES"
Confirm overwriting by pressing **Enter**.
If you do not want to overwrite the existing program, select "NO" using the **Sel** key, press **Enter** and enter a new name. Confirm the new name by pressing **Enter**.

```
- - - Edit UNNAMED - - - -  
Testing  
TEST exists  
Overwrite: YES
```

If a program is not saved ("Save:NO"), it remains in the processing level and can be supplemented or modified by calling up "Edit". Safety checks in other sub-items prevent a program which has not been saved from being accidentally overwritten.

The internal memory can accommodate a maximum of 99 programs. The number possible depends on the length of the programs.

The program in the processing level can be started by pressing the **Start/Stop** key.

Note: The procedure for saving programs on a personal card is described in Sec. 9.3.

7.3 Modifying a program

A program which is already in the internal memory or on a personal card can be modified by being loaded into the processing level. The program resident in the "Edit" processing level is thus deleted. If a program which has not yet been saved is in the processing level, it can be saved following a safety check prior to deletion.

- Select the "FILES" menu using the **▼** or **▲** key
and confirm by pressing **Enter**.

```
Main-Menu | Start  
STANDARD | → FILES..  
- - /25.0° | OPT ....  
10:38:45 | Lid Incu
```

- Select the "Load" menu using the **▼** or **▲** key
and call up by pressing **Enter**.

```
Main-Menu | Edit  
STANDARD | → Load  
- - /25.0° | Standard  
10:38:45 | New Del
```

7 Programming

A list of existing programs appears in the display.

```
- - - Load to Editor - - - -  
→ Standard  
TEST1  
TEST2
```

- Select the program using the  or  key and load by pressing .

```
- - - Edit STANDARD - - - -  
CNTRL          BLOCK  
LID=105°  
NOWAIT        AUTO
```

- Using the , , ,  keys or , move the flashing cursor onto the parameter which is to be changed.
- Enter data using the numeric keypad or select between settings using the  key or enter letters using the .

Inserting a program line

- Move the flashing cursor onto the number of the program line in front of which a new command is to be inserted.
- Press the  key. A new line is inserted above the cursor.
- Select the wanted command using the .

Note: Press the  key for entering options regarding the temperature command. In this case, the cursor must be positioned on the program line number in front of the temperature command.

Deleting a program line

- Move the flashing cursor to the program line number.
- Press the  key. The line is deleted.
- After a program has been changed, exit the "Edit" processing level by pressing the  key.
- Confirm the safety check "Save:YES" by pressing .
- The modified program can be saved using the same name, in which the old program is overwritten. Confirm the check "Overwrite:YES" by pressing .

If the program should not be overwritten, and a new program is to be created, answer "Overwrite:" with "NO" ( and  keys) and enter a new program name with  or the numeric keypad.

Caution: If the changed program is not stored, there will be two different programs with the same name. The program which has been changed is in the processing level and the program which has not been changed is in the device memory.

The modified program can be started in the processing level .

- After the end of the program "End of Program" appears in the display. Press the  key.
- If you now want to save the program which has been changed, select "Load" menu with  and press . "Program not saved – Save YES" appears in the display.
- Press  to save the program.

7 Programming

7.4 Creating programs using an example program

It is possible to program quickly with the aid of the "Standard" example program. A program does not need to be completely rewritten; the sample can be supplemented, modified and then saved under a new name.

- Select the "FILES" menu and call up by pressing .
- Select "Standard" and call up by pressing .

The example program is loaded into the processing level. It is structured in the following way:

	CNTRL	BLOCK	Temperature control for the block.
	LID=105°		Sets heated lid to 105 °C.
	NOWAIT	AUTO	NOWAIT = Program is started immediately. AUTO = Lid heating is switched off automatically when temperature (22 °C) is maintained for more than 5 minutes.
1	T=94.0°	0:02:00	Maintains 94 °C for 2 min. (initial denaturation)
2	T=94.0°	0:00:15	Maintains 94 °C for 15 secs. (denaturation)
3	T=44.0°	0:00:15	Maintains 44 °C for 15 secs. (annealing)
4	T=72.0°	0:00:30	Maintains 72 °C for 30 secs. (elongation)
5	GOTO 2	REP 24	Repeats 24 times from program step 2 onwards. The total number of cycles is 25.
6	T=72.0°	0:00:30	Maintains 72 °C for 30 secs. (final elongation)
7	HOLD 22.0°	ENTER	Cools down to 22 °C and maintains temperature.
	end		Program end

Although the example program cannot be deleted, individual changes can be made. After changes have been made, the example program must be saved under the name "Standard". To restore the original example program, the "Standard" program in the "Del" sub-menu must be deleted. When "Standard" is called up, the original example program is reloaded into the processing level.

7.5 Deleting a program

- Select the "FILES" menu and call up by pressing .
 - Select "Delete" and call up by pressing .
- A list of the existing programs appears in the display.

```
- - - Delete Program- - - -  
→ TEST1  
TEST2
```

- Select the program name.
- Confirm by pressing . The program is deleted.

The procedure for deleting programs on a personal card is described in Sec. 9.3.

7 Programming

7.6 Examples of programming

The following passage contains several examples of the versatility of the commands and functions of the Mastercycler® personal.

7.6.1 Using the "Pause" and "Hold" commands (Example: Hot Start PCR)

The "Pause" command is used to interrupt the program. The most-recently entered temperature is maintained. A text explaining the reason for the interruption may be entered as required. After confirmation by pressing , the program is continued.

The "Hold" command enables all possible temperatures to be maintained until the program is continued by pressing .

In the example of a Hot Start PCR listed below, the program is stopped following initial denaturation in order to add a reaction component. After the final elongation, the block is cooled down to room temperature.

Hot Start PCR			
	Temperature control of tubes	Control	tube
	Temperature control of lid	lid	105°
		Nowait	auto
1	Initial denaturation	94°	2 min
2	Pause for adding substance	Pause	Adding
3	Denaturation	94°	15 sec
4	Annealing	55°	15 sec
5	Elongation	72°	30 sec
6	Number of cycles	go to 3	Rep 29
7	Final elongation	72°	2 min
8	Cooling and storage	Hold 20°	enter
	End	end	

7 Programming

7.6.2 The temperature increment (Example: Touch Down PCR)

The temperature increment, which can be programmed as desired with every temperature command, allows the temperature to be reduced or increased by a defined value with every cycle.

Touch Down PCR can be used to increase the specificity of the PCR by changing the the annealing temperature in succession from higher to lower temperatures.

In the example given, the annealing temperature is reduced by 1 °C per cycle for the first 16 cycles, until 50 °C has been attained. At this annealing temperature, 14 additional cycles are carried out.

<i>Touch Down PCR</i>			
	Temperature control of tube	Control	tube
	Temperature control of lid	lid	105°
		Nowait	auto
1	Initial denaturation	94°	2 min
2	Denaturation	94°	15 sec
3	Annealing	65°	15 sec
	<i>Temperature increment</i>	<i>-1°</i>	
4	Elongation	72°	30 sec
5	Number of cycles	go to 2	Rep 15
6	Denaturation	94°	15 sec
7	Annealing	50°	15 sec
8	Elongation	72°	30 sec
9	Number of cycles	go to 6	Rep 13
10	Final elongation	72°	2 min
11	Cooling and storage	Hold 20°	enter
	End	end	

7 Programming

7.6.3 The time increment (Example: Long PCR)

The time increment, which can be programmed as desired with every temperature command, enables a defined extension of the lag time at a specific temperature for each cycle.

With Long PCR, this function can be used to amplify long fragments for a successive extension of the elongation.

In the example given, the elongation time is extended by 10 seconds for each cycle, which means that, for the 30th cycle, the elongation time is 290 seconds longer than for the first cycle.

<i>Long PCR</i>			
	Temperature control of tubes	Control	tube
	Temperature control of lid	lid	105°
		Nowait	auto
1	Initial denaturation	94°	2 min
2	Denaturation	94°	15 sec
3	Elongation	68°	10 min
	<i>Time increment</i>		<i>+0:10 sec</i>
4	Number of cycles	go to 2	Rep 29
5	Final elongation	72°	15 min
6	Cooling and storage	Hold 20°	enter
	End	end	

7 Programming

7.6.4 Regulating the temperature-control speed (Example: RAPD-PCR)

Variable heating and cooling rates, which can be programmed as desired with each temperature command, enable the temperature-control speed to be aligned to the temperature.

With the RAPD-PCR process or with PCR with A/T-rich primer/template hybrids, it may be necessary to heat up carefully after annealing.

In the example given, the elongation temperature is attained at a speed of 1 K/s.

RAPD-PCR			
	Temperature control of tube	Control	tube
	Temperature control of lid	lid	105°
		Nowait	auto
1	Initial denaturation	94°	2 min
2	Denaturation	94°	15 sec
3	Annealing	55°	15 sec
4	Elongation	72°	30 sec
	Heating rate	R = 1 °/s	
5	Number of cycles	go to 2	Rep 29
6	Final elongation	72°	2 min
7	Cooling and storage	Hold 20°	enter
	End	end	

Temperature-control speeds, which may be as slow as the user desires, can be selected by means of program loops, with which a gradual change in temperature is obtained via temperature increments.

In the following example, the elongation temperature is raised slowly to 72 °C after annealing with the aid of a program loop.

RAPD-PCR			
	Temperature control of tube	Control	tube
	Temperature control of lid	lid	105°
		Nowait	auto
1	Initial denaturation	94°	2 min
2	Denaturation	94°	15 sec
3	Annealing	55°	15 sec
4	Elongation	56°	7 sec
	Temperature increment	+1°	
	Heating rate	R = 0.3 °/s	
5	Number of cycles	go to 4	Rep 16
6	Number of cycles	go to 2	Rep 29
7	Final elongation	72°	2 min
8	Cooling and storage	Hold 20°	enter
	End	end	

7 Programming

7.6.5 Sample cooling and subsequent PCR

If sensitive samples should remain cooled until the PCR takes place, the thermoblock must be preheated. This can be carried out in two ways:

1. Set the "Incu" menu to 4 °C and "Heater is On".
2. Adapt an initial program and connect via a "LINK" command.
For this purpose, the temperature of the thermoblock is brought to 4 °C using the first program. After the samples have been inserted into the cold thermoblock, the second program with the PCR protocol is called up via a LINK command.

Programming should take place as follows:

Program 1	e.g. COOL
CNTRL TUBE	The entries in the first program are also valid for the programs which are added via LINK. The lid setting "Fix" must be selected.
Lid	
NOWAIT FIX	
1 Hold 4 °C Enter	The thermoblock cools until the processing program (e.g. PCRPROT) is started via the LINK command by pressing <input type="button" value="Enter"/> .
2. Link PCRPROT	Link to the second program with the PCR protocol.
end	
Program 2	PCRPROT
CNTRL TUBE	If the program also contains the "Tube control" command, further entries for tube type and filling volume are no longer necessary; the entries made for the first program are valid for all further programs.

8 Short instructions

It is essential to read the operating manual completely before working with the short instructions.

Switching on the device

Menu name _____	Main-Menu → Start	_____	To start any program
Program in processing level _____	STANDARD FILES..	_____	Programming
Nominal/actual block temperature _____	-- /25.0° OPT	_____	System setting
Time _____	10:38:45 Lid Incu	_____	To temperature-control block and heated lid
		_____	Lid temperature

Programming

- Select the FILES menu using the ▲ / ▼ keys and press .

- Edit To edit the program in the processing level
- Load To load and edit any program
- Standard To load and process the example program
- New To create a new program
- Del To delete any program

```
FILES . . | → Edit
STANDARD | Load
-- /25.0° | Standard
10:38:45 | New Del
```

Changing the "Standard" example program

- Select "Standard" using the ▼ key and press .
- Using the ▲, ▼, ◀, ▶ keys, move the cursor to or between the entry positions.
- Select the program commands using the key, enter the settings or the texts and confirm by pressing .

- CNTRL To define temperature regulation
- BLOCK For the thermoblock
- TUBE For different tubes
- Lid To determine the lid temperature
- NOWAIT To start a program immediately
- WAIT Program waits for lid temperature
- AUTO Lid switches off at <22 °C and time >5 min.
- FIX Lid switches off at end of program

```
- - - Edit STANDARD - - - -
CNTRL BLOCK
LID=0°
NOWAIT AUTO
```

Program commands

- T Temperatures, times, increments, ramp
- HOLD To maintain temperature entered until program is continued with **Enter** (4–99 °C)
- PAUSE To interrupt program until program is continued with **Enter** (0–11 characters)
- GOTO/REP To repeat program parts and number of cycles (1–40 lines, 1–99 repeats)
- SOUND Acoustic signal (1–10 tones)
- LINK To branch to other programs (1–5 programs)

- Enter the options for the temperature command using the key. The cursor must be positioned on the program line number.

- | | | |
|---|--|--|
| T | Temperature (0–99°), | Time (0:00:01–9:59:59) |
| | Temperature increment
(0.0–10.0°, + or –) | Time increment
(0:00–1:00, + or –) |
| R | Ramp (0.3–3 K/s), | Ramp increment
(0.1–1.0 °/s + or –) |

```
- - - Edit STANDARD - - - -
4 T=72.0° 0:00:30
+0.0° +0:00
R=3.0°/s +0.0°/s
```

- Confirm entries by pressing .
- Complete programming by pressing .
- Save the program.

8 Short instructions

Saving a program

- Exit the program using the key.
- Answer the question "Save: YES" by pressing .
- Define the program name using the key.
- Confirm the name by pressing .

```
- - - Edit STANDARD - - - -
STANDARD not saved
Save: YES
ProgName: TEST 2
```

Adding a program line

- Using the / keys, move the cursor onto the program line number.
- Press the key; a new line is then added above the cursor. Select command required with .

Deleting a program line

- Using the / keys, move the cursor onto the program line number.
- Press the key; the line is then deleted and the cursor moves to the next line.

System settings

To temperature-control lid and block	Incu menu	Block temperature 37 °C, Heater is ON
To preheat the lid	Lid menu	LidTemp 105 °C, Heater is ON
To print programming	OPT menu	Printout Editor: YES
To print program sequence	OPT menu	PrintProtocol: ON

Starting a program

- Switch on the device. If necessary, preheat the lid and the block.
- Select the "Start" menu using the / keys and press .
- Select the program name using the / keys and press .
- With CNTRL TUBE, select the tube type using the key.
Enter the filling volume.
0.2 ml/plate: 5 to 50 µl
0.5 ml/thin: 5 to 100 µl
- Confirm by pressing . The program starts immediately.
- To see the program run time, press the key.

```
→ STANDARD
TEST1
TEST2
```

```
1 T=94.0° 0:02:00
95.0/94.7° 0:01:02
Lid:105° Cyc: 1
```

Interrupting a program

- Press the key.
- Using the key, select the "Pause" program.
- Confirm by pressing .

```
STANDARD running . . .
Program: STOP
94.0/93.9°
Lid:105°
```

Continuing an interrupted program

- Press the key.
- Using the key, select "Resume".
- Confirm by pressing .

Stopping a program

- Press the key.
- Confirm "Stop" by pressing .
- Exit the program by pressing .

```
Main-Menu | → Start
STANDARD | FILES..
- - /25.0° | OPT ...
10:38:45 | Lid Incu
```

9 Personal card

Depending on the length of the program, a maximum of ten programs can be stored on a personal card. When a program is started from a personal card, the program is loaded into a temporary memory (but not into the internal memory or into the processing level) for the duration of the program processing.

Programs can be transferred to other devices of the Mastercycler[®], Mastercycler[®] gradient and Mastercycler[®] personal using the personal card.

For the "Start", "FILES/Load", "FILES/Edit" and "FILES/Del" menus, a difference will be made between the memory of the personal card (MCARD) and the internal memory of the Mastercycler[®] personal (INTERN) only when the personal card has been inserted.

Menus "Start", "FILES/Load" and "FILES/Del"

Only the programs of a memory appear in the display. The memory which is currently closed appears in the display at the head of a program list as (INTERN) or (MCARD). The closed memory can be opened by selecting and then confirmed by pressing . This also closes the previous memory.

Menu "FILES/Edit"

The memory target (Target) must be selected using the key before the program name is determined.

9.1 Safety precautions

The gold-colored contact area on the personal card must not be damaged, scratched or contaminated in any way. Avoid touching the contact area with your fingers.

Electrostatic charges can destroy stored programs.

9.2 Operation

Inserting the card

- With the arrow facing forwards and the gold-colored contact area facing upwards, insert the card into the slot under the control panel.
- Insert the card up to the stop. It clicks into place automatically.

Removing the card

- Insert the card up to the stop.
- The card is pushed out by spring pressure and can then be removed.

Formatting the card

A new card must be formatted. The request for formatting appears automatically in the display only when it is necessary. The request for formatting is also made if the card has been erroneously inscribed.

- "Memory card not valid"
Confirm "Format: Yes" by pressing .

The nominal/actual steps appear in the bottom line of the display.

9 Personal card

9.3 Processing programs

Starting a program from a card

- Select the "Start" menu item and call up by pressing .
- Select ⟨MCARD⟩ and call up by pressing .
If the memory name ⟨INTERN⟩ appears in the display instead of ⟨MCARD⟩, this means that the program memory of the personal card has already been opened.
- Select a program and call up by pressing .

Note: For starting purposes, programs are not loaded into the internal memory or into the "Edit" processing level. After the program has ended, the program which has been started by the card is no longer available on the Mastercycler[®] personal.

Deleting a program from a card

- Select the "FILES/Del" menu and call up by pressing .
- Select ⟨MCARD⟩ and call up by pressing .
If the memory name ⟨INTERN⟩ appears in the display instead of ⟨MCARD⟩, this means that the program memory of the personal card has already been opened.
- Select a program and delete by pressing .

Loading a program from a card into the processing level

- Select the "FILES/Load" menu and call up by pressing .
- Select ⟨MCARD⟩ and call up by pressing .
If the memory name ⟨INTERN⟩ appears in the display instead of ⟨MCARD⟩, this means that the program memory of the personal card has already been opened.
- Select a program and load by pressing .

Saving a program on a card

- After a program has been compiled or modified, exit the processing level by pressing .
- Confirm the inquiry "Save: YES" by pressing .
- For the inquiry "Target:INTERN", select ⟨MCARD⟩ using the key and confirm by pressing .
- Enter the program name (max. 8 characters) and confirm by pressing .

Note: The program can be saved under the same name as in the memory of the Mastercycler.

Programs with LINK commands

A program cannot be started from a personal card if it contains program branching – LINK commands – to other programs on the personal card. It is possible to start the program if branching to another program in the internal memory of the Mastercycler[®] personal is available.

A program from the internal memory cannot call up a program from the personal card using a LINK command.

10 Interface description

10.1 Printer / PC connection

Printer connection

The printer connection socket (25 pins, Centronics parallel interface, PC compatible) is located below the PC connection socket on the right-hand side of the device (see Sec. 4.1, Fig. 2.5).

Connect the Mastercycler[®] personal and printer via a commercially available PC printer cable. The cyclor and printer must be switched off during installation. If the printer is not used frequently, the printer cable should be disconnected from the cyclor port and only be installed when needed.

The parameters for the printer are set in the "OPT/Printer" menu.

Print programming

Printout Editor: NO

Printing is switched off.

Printout Editor: YES

The program in the "Edit" menu is printed out.

Select "YES" using the key and confirm by pressing .

"Printout Editor: NO" is selected automatically after the printout.

Print program protocol

Print Protocol: OFF

The program sequence is not printed out.

Print Protocol: ON

The program sequence is printed out.

10 Interface description

Example of a program printout:

```

** MASTER CYCLER personal 5332 **
  eppendorf
  Version x.xx.xx
  Time: 13:41:02
  Date: 14/Apr/1999
*****

LISTING
Program:          STANDARD      Program name
Created:          13/Apr/1999   11:46   Date last stored
Step:
  CNTRL          BLOCK
  LID=105C
  NOWAIT        AUTO

1   T = 94.0C    0:02:00
    +0.0C        + 0:00
    R = 3.0C/s   +0.0C/s

2   T = 44.0C    0:00:15
    +0.0C        + 0:00
    R = 3.0C/s   +0.0C/s

.   .
.   .
.   .

7   HOLD 22.0C  ENTER

END OF LISTING
```

10 Interface description

Example of a program protocol:

Prior to the start, the program is printed (see page 42) and during the program sequence, all temperatures and times are printed in a protocol.

Program ... started at	–	Date and time of start of program
Initial Blocktemp	–	Block temperature at start
Initial Lidtemp	–	Lid temperature at start
Run Time	–	Estimated run time
Finish Time	–	Estimated time for end of program
Count	–	Count of program steps
Cycle	–	Count of cycles
Step	–	Program step no. from programming
Command	–	Command type and programmed values
Time	–	Time at end of a command
Completion Time	–	Time at end of program

Program STANDARD started at	Date:	15/Apr/1999	1:50:03		
Initial Blocktemp:	20.0 C				
Initial Lidtemp:	22 C				
Run Time:	1:06				
Finish Time:	15/Apr/1999	2:59			
Count	Cycle	Step	Command	Time	
			Tube:0.2 ml	Fill.Vol.:20 µl	
			CNTRL	TUBE	1:50:07
			LID=105C		
			NOWAIT	AUTO	1:50:08
1	1	1	T=94.0C	0:02:00	
			+0.0C	+ 0:00	
			R=3.0C/s	+0.0C/s	1:52:28
2	1	2	T=94.0C	0:00:15	
			+0.0C	+ 0:00	
			R=3.0C/s	+0.0C/s	1:52:46
.					
.					
Completion Time:	15/Apr/1999	2:59:50			
END OF PROTOCOL					

10 Interface description

PC connection

The 9 pin PC connection socket (serial interface RS 232) is located above the printer port on the right-hand side of the device (see Sec. 4.1, Fig. 2.5).

The parameters for the computer are set in the "OPT/GEN/Remote" menu.

Selection of transfer rate: Baud rate 19,200, 9,600, 4,800, 2,400 or 1,200

Detailed information about PC connection and the connecting cable required is available on request.

The computer to be connected must correspond to the EN 60950 or UL 1950 regulations.

A special operating manual is available for serial communication. Further information is available on request.

10.2 Program transfer

If programs are stored on a personal card, they can be transferred via the card to other Mastercycler[®], Mastercycler[®] gradient and Mastercycler[®] personal devices. Programs created on a Mastercycler[®] personal can also be transferred to a Mastercycler[®] gradient. The Mastercycler[®] gradient has an additional function, whereby a Gradient function is added to the temperature command, i.e. a temperature gradient can be built up in the thermoblock. This function cannot be used when programs are transferred to the Mastercycler[®] and Mastercycler[®] personal.

11 Maintenance

The Mastercycler® personal can be cleaned using water or a mild laboratory cleaning agent.

The device should not come into contact with organic solvents or aggressive solutions. Ensure that no liquid enters the device. For safety reasons, the device must be switched off and disconnected from the power supply before cleaning begins.

The electrical safety fuses are located between the main power switch and the main power plug at the rear of the device. They can be removed by sliding them up one catch. Before the fuses are replaced, the device must be switched off and disconnected from the mains supply. Only fuses with the correct voltage values may be used (information on the fuse type can be found at the rear of the device).

The device may only be opened by qualified service personnel. The warranty will not be honored in the event of damage caused by unauthorized servicing.

12 Troubleshooting

Programming errors or errors regarding the handling of the personal card can be eliminated after the cause of the error has been established.

Technical errors can be caused by interference (e.g. power failure or power fluctuations). In some cases, it is possible to eliminate the error by switching off the device for a short period. Wait ten seconds before switching on the device again. If the error recurs, contact a service technician.

12.1 Error messages

<i>Error message</i>	<i>Cause</i>	<i>Solution</i>
BLOCK ChkSumErr	Technical defect.	Contact SERVICE.
BLOCK DEFECTIVE!	Electronics, heating or fuse defective.	Contact SERVICE.
BLOCK TOO HOT!	Defective regulation or defective electronics.	Contact SERVICE.
Card changed	Card removed immediately before being inscribed.	Insert card correctly and repeat procedure.
Card content not o.k.	Content of card is defective.	Card must be formatted. Automatic procedure when program is saved.
Card not in slot	Card removed during saving process.	Insert card correctly and repeat procedure.
Enter Tube	Not all entries have been made for a program which has been started.	Enter tube type and sample volume.
Err GOTO (1)	Branching to a program line number is impossible because this program line number is in a program area which has already been selected for repeating using another GOTO command.	Check GOTO command and modify or delete if necessary. Program line number for additional GOTO command must not be in a section which is already addressed by a GOTO command.
Err GOTO (2)	More than three GOTO commands used for one program range.	Three GOTO commands can be used in one program range when the areas which have been addressed overlay each other completely, i.e. the program area of the second command is greater than that of the first command. The third GOTO command must cover an even greater area than that of the second command.
Err Invalid	Invalid command. Parameter has not been entered.	Enter command completely or delete command.

12 Troubleshooting

<i>Error message</i>	<i>Cause</i>	<i>Solution</i>
Err Link (1) ... Line ..	LINK command cannot be executed. Program not found. Program name and program line of defective LINK command appear in the display.	Only programs from the internal memory can be called up by the LINK command. Programs on a personal card and the program in the processing level ("Edit") cannot be called up by the LINK command.
Err Link (2) ... Line ..	Too many programs are connected by LINK commands. Program name and program line of defective LINK command appear in the display.	A maximum of five programs, i.e. four LINK commands, can be processed in succession.
Err No Program	No executable program available in memory.	Load program from memory or personal card, or define a program in "Edit" menu and restart.
FAT Full	Number of programs which can be administrated has been exceeded. Internal memory: 99 programs personal card: 10 programs	Delete programs which are not required.
Internal EE-Err	Technical defect.	Contact SERVICE.
LID TOO HOT!	Defective electronics.	Contact SERVICE.
Link not found	Program branching is not possible because the program which was supposed to be called up has been deleted.	Check the LINK command. Enter the missing program.
Link Error	Program branching is not possible because the program which was supposed to be called up has been deleted.	Check the LINK command. Enter the missing program.
MCard Error	The memory of the personal card is defective.	Evaluate further messages.
Memory corrupted	The internal memory is defective.	The internal memory must be deleted. This deletes all programs.
Memory Error	The internal memory for programs is defective.	Evaluate further messages.
Memory full!	Memory is full.	Before storing, delete programs which are not required.

12 Troubleshooting

<i>Error message</i>	<i>Cause</i>	<i>Solution</i>
MemoryCard Defective!	Card is defective.	Use a new card.
MemoryCard HdChksumErr	Error in check sum.	Card must be formatted. Automatic procedure when program is saved.
MemoryCard ManIDErr	Incorrect identification.	Card must be formatted. Automatic procedure when program is saved.
MemoryCard MemOverErr!	Incorrect memory address.	Card must be formatted. Automatic procedure when program is saved.
MemoryCard MemRangeErr	Error in memory range.	Card must be formatted. Automatic procedure when program is saved.
MemoryCard MemSizeErr	Incorrect memory size.	Card must be formatted. Automatic procedure when program is saved.
MemoryCard MemUnderErr!	Incorrect memory address.	Card must be formatted. Automatic procedure when program is saved.
MemoryCard Missing!	No card has been inserted.	Insert card.
MemoryCard Not Valid	Card is invalid.	<ul style="list-style-type: none"> – Insert card correctly (check that card is facing in the correct direction). – Card should be formatted before saving begins.
MemoryCard Read Err!	Card cannot be read.	Insert card correctly (check that card is facing in the correct direction).
MemoryCard Read-Only!	Card is marked as write-protected.	Card must be formatted. Automatic procedure when program is saved.
MemoryCard Blank	Card has incorrect logical identification and/or is blank.	Card must be formatted. Automatic procedure when program is saved.

12 Troubleshooting

<i>Error message</i>	<i>Cause</i>	<i>Solution</i>
MemoryCard Write Err!	Writing error on card.	<ul style="list-style-type: none"> – Insert card correctly (check that card is facing in correct direction). – Do not touch/move card during saving.
Name Invalid!	Program name contains an invalid character.	Enter program name again.
POWER ERROR!	Voltage error or defective fuse.	Contact SERVICE.
Printer: OFF LINE	Printer is not ready to receive.	Select the "ON LINE" printer setting.
Printer: no response	No printer is available or the printer is not switched on.	<ul style="list-style-type: none"> – Select "OFF" in the menu OPTION/Printer/Print Protocol. – Switch on the printer.
Program is running!	A program is being processed.	Lid temperature cannot be modified at the moment.
Program too large!	Program is too large.	Max. 40 program lines possible.
Restarting Program!	A power failure occurs or the device is switched off briefly when a program is running.	The program continues automatically.
SENSORxxERROR!	Defective temperature sensor.	Contact SERVICE.
SLOWING DOWN!	The heating rate or cooling rate has slowed down.	If error recurs, contact SERVICE.
Steps free	Display of free memory spaces is < 100 steps. 1 step = 1 program line.	Delete programs which are not required or store them on the personal card.
TSensor_Err	<ul style="list-style-type: none"> – Permitted operating conditions have not been maintained. – Technical defect. 	<ul style="list-style-type: none"> – Operate device at permitted temperature and humidity only. – Contact SERVICE.
Value out of range!	Value is not within the permitted value range.	The closest permitted value is entered automatically.
Warn Ramp Max ... Line ...	The ramp is limited to 3 K/s.	Check entries for ramp and ramp increment, and change entries if necessary.
Warn Ramp Min ... Line ...	The ramp is limited to 0.3 K/s.	Check entries for ramp and ramp increment, and change entries if necessary.

12 Troubleshooting

<i>Error message</i>	<i>Cause</i>	<i>Solution</i>
Warn Temp Max	Temperature limits of 99 °C exceeded. If program is started, temperature is limited to 99 °C.	Check temperature commands and reduce value of temperature increment so that only values below 99 °C can be reached.
Warn Temp Min	Temperature limit of 4 °C not reached. If program is started, temperature is limited to 4 °C.	Check temperature commands and modify values of temperature increment so that only values above 4 °C can be reached.
Warn Time Max	Cycle time of 9:59:59 exceeded. If program is started, cycle time is limited to 9:59:59.	Check temperature commands and modify values of time increment so that only values below 9:59:59 can be reached.
Warn Time Min	Cycle time of 0:00:01 not reached. If program is started, cycle time is limited to 0:00:01.	Check temperature commands and modify values of time increment so that only values above 0:00:01 can be reached.

13 Technical data

Mastercycler[®] personal

Sample capacity:	1 microtiter plate or 25 0.2 ml PCR tubes or 16 0.5 ml PCR tubes, thin-walled
Temperature range:	4 to 99 °C
Temperature uniformity across the block:	95 °C ± 1.0 K 20 to 72 °C ± 0.6 K
Control accuracy:	± 0.2 °C
Temperature-control speed:	Heating rate: approx. 3 K/s, measured on the block Cooling rate: approx. 2 K/s, measured on the block
Number of programs:	max. 99 max. 10 on a personal card
Maximum number of cycles:	99
Dimensions:	Width: 18 cm Depth: 35 cm Height: 25 cm
Weight:	approx. 6.8 kg
Voltage/frequency:	230 V, 50–60 Hz 115 V, 50–60 Hz 100 V, 50–60 Hz
Power requirement:	150 W 150 W 170 W
Operating current:	0.8 A 1.6 A 2.1 A
Fuses:	2 x T 2 A, 250 V 2 x T 3.15 A, 250 V 2 x T 3.15 A, 250 V
Overvoltage category:	II
Pollution degree:	1
Contamination level:	I
Operating conditions:	15 to 35 °C, 70 % rel. humidity
Storage conditions:	–20 to 70 °C, 85 % rel. humidity

The device is -approved, fulfills UL 3101-1 and CSA C 22.2 No. 1010.1.

Technical specifications subject to change!

14 Ordering information

Please use only the accessories recommended by Eppendorf. Using disposables which we have not recommended can reduce the precision, accuracy and life of the device. We do not honor any warranty or accept any responsibility for damage resulting from such action.

Order no.

Description

5332 000.014	Mastercycler® personal 5332 230 V, 50–60 Hz
5332 000.049	115 V, 50–60 Hz

Accessories

5332 900.066	Operating manual
5332 300.018	Personal card
5331 226.027	Personal card for temperature-validation system
0013 608.130	Fuse, time-lag, 2 A, 250 V, for version 230 V (50–60 Hz) (1 pc.)
0013 609.098	Fuse, time-lag, 3,15 A, 250 V, for version 100 und 115 V (1 pc.)
0055 000.298	Temperature-validation system

Consumables

0030 124.332	PCR tubes 0.2 ml, colorless (1000 pcs.)
0030 124.502	PCR tubes 0.5 ml, colorless, thin-walled (500 pcs.)
0030 124.340	PCR tubes 0.2 ml, colorless, 5-strip (125 pcs.)
0030 127.455	PCR Rack, random colors (10 pcs.)
0030 123.301	Safe-Lock microcentrifuge tubes, 0.5 ml, colorless (500 pcs.), PCR clean

Recommended auxiliary equipment

5425 715.005	Adapter for 0.2 ml PCR tubes for 1.5/2.0 ml rotor (6 pcs.) *
5425 716.001	Adapter for 0.5/0.6 ml tubes for 1.5/2.0 ml rotor (6 pcs.) *
4830 000.017	Eppendorf Biomaster® 4830 and Mastertips® for contamination-free pipetting according to the positive-displacement principle in the volume range from 1 µl to 20 µl Biomaster Kit = 1 Biomaster and 96 Mastertips
3881 000.015	PCR-Cooler 0.2 ml Starter Set (1 x pink, 1 x blue)
3881 000.023	PCR-Cooler 0.2 ml pink
3881 000.031	PCR-Cooler 0.2 ml blue

* For centrifugation

14 Ordering information



14 a Ordering information for North America

Please use only the accessories recommended by Eppendorf. Using disposables which we have not recommended can reduce the precision, accuracy and life of the device. We do not honor any warranty or accept any responsibility for damage resulting from such action.

Order no.	Description
950000040	Mastercycler® personal 5332
950000031	230 V, 50–60 Hz 115 V, 50–60 Hz
Accessories	
950002522	Operating manual
950007010	Personal card
950008008	Temperature-validation system
Consumables	
951010006	PCR tubes 0.2 ml, colorless (1000 pcs.)
951010057	PCR tubes 0.5 ml, colorless, thin-walled (500 pcs.)
951010014	PCR tubes 0.2 ml, colorless, 5-strip (125 pcs.)
951010065	PCR Rack, random colors (10 pcs.)
22363719	Safe-Lock microcentrifuge tubes, 0.5 ml, colorless (500 pcs.), PCR clean
Recommended auxiliary equipment	
22636260	Adapter for 0.2 ml PCR tubes for 1.5/2.0 ml rotor (6 pcs.) *
22636227	Adapter for 0.5/0.6 ml tubes for 1.5/2.0 ml rotor (6 pcs.) *
22440501	Eppendorf Positive Displacement Pipette Model 4830 1 Kit = 1 Pipette Plus 96 Mastertips 100 Safe-Lock tubes (0.5 ml)i
22510509	PCR-Cooler 0.2 ml Starter Set (1 x pink, 1 x blue)
22510541	PCR-Cooler 0.2 ml pink
22510525	PCR-Cooler 0.2 ml blue

* For centrifugation

14 a Ordering information for North America



15 Index

A

Actual temperature 75
Annealing 82, 83

B

Baud rate 69
BLOCK 74, 81

C

Command
 AUTO 79, 93
 CNTRL 73, 74, 78, 93
 FIX 79, 93
 GOTO 81, 102
 GOTO/REP 93
 HOLD 80, 84, 92
 LINK 81, 96, 103
 NOWAIT 73, 79, 93
 PAUSE 81, 88
 SOUND 81
 WAIT 73, 79, 93
Creating new programs 82
Cursor 63, 64, 86
Cycle 84
 time 79, 106

D

Display 64
Denaturation 82, 83

E

Elongation 82
END 81
Entering date 69
Example program 67, 87, 93

F

Filling volume 74, 78

H

Heated lid 60, 70, 71, 73, 79

I

INTERN 95, 96

L

Locking button 62

M

Main menu 65, 74, 75
Main power switch 62
Maintenance 101
MCARD 95, 96
Menu
 Delete 67, 93
 Edit 66, 93
 Editor 68, 97
 FILES 66
 GENERAL 69
 Incubate 71, 73
 Lid 70, 79
 Load 67
 New 67, 82, 93
 OPTIONS 68, 97
 Printer 68
 Standard 67, 87
 Start 66
 VALID 70

N

Nominal temperature 75

O

Ordering information 108

P

Pause 76, 94
PC connection socket 62
Peltier element 59
Personal card 61, 95, 102, 104
 reader 62
Power failure 69, 70
Printer connection socket 62, 97
Processing level 64, 65, 66, 67, 74, 85,
 93, 96

Program

 line, adding 86
 line, deleting 86
 line number 79, 81, 93, 94
 name 66, 67, 84, 96
 sequence 99
 sequence, printing 94, 97
 – aborting 64, 77, 94
 – changing 85, 86
 – continuing 76, 94
 – deleting 87, 93
 – interrupting 64, 76
 – loading 85
 – saving: see "storing"
 – starting 74
 – storing 66, 84, 94
 – transferring 100

15 Index

R

Ramp 79, 80, 91, 93, 105
Ramp increment 79, 80, 93
Restart 69
Resume 76, 94
Reverse sign 63
Run 76
Run time 63, 70, 75

S

Safety precautions 60, 95
Sample
 quantity 73
 tube 72
Setting the time 69
Signal 69
Startup 60, 61
Stop 76

T

Temperature 75, 79, 81, 83, 93, 106
 increment 79, 80, 89, 91, 93, 106
 options 68
Thermblock 59, 60, 71, 72, 73
Time increment 78, 80, 90, 93, 106
Tube control 59, 78
Tube type 73, 74, 94

V

Ventilation 60
 slit 61, 62

EG-Konformitätserklärung EC Conformity Declaration

Das bezeichnete Produkt entspricht den einschlägigen grundlegenden Anforderungen der aufgeführten EG-Richtlinien und Normen. Bei einer nicht mit uns abgestimmten Änderung des Produktes oder einer nicht bestimmungsgemäßen Anwendung verliert diese Erklärung ihre Gültigkeit.

The product named below fulfills the relevant fundamental requirements of the EC directives and standards listed. In the case of unauthorized modifications to the product or an unintended use this declaration becomes invalid.

Produktbezeichnung, Product name:

Mastercycler[®] personal

Produkttyp, Product type:

Thermocycler zur DNA-Vervielfältigung / Thermocycler for DNA amplification

Einschlägige EG-Richtlinien/Normen, Relevant EC directives/standards:

2006/95/EG, EN 61010-1, EN 61010-2-10/A1

2004/108/EG, EN 55011/B, EN 61000-6-1, EN 61000-3-2, EN 61000-3-3



Vorstand/Board of Management:

21.05.2007

Hamburg, Date:



Projektmanagement, Project Management:

eppendorf



Eppendorf AG · Barkhausenweg 1 · 22339 Hamburg · Germany

Eppendorf Offices

AUSTRALIA / NEW ZEALAND

Eppendorf South Pacific Pty. Ltd.
Tel. +61 2 98 89 50 00
Fax +61 2 98 89 51 11
E-mail: Info@eppendorf.com.au
Internet: www.eppendorf.com.au

AUSTRIA

Eppendorf Austria
Tel. +43 1 2901756-0
Fax +43 1 2901756-20
E-Mail: office@eppendorf.at
Internet: www.eppendorf.at

BRAZIL

Eppendorf do Brasil Ltda.
Tel. +55 11 3095 9344
Fax +55 11 3095 9340
E-Mail: eppendorf@eppendorf.com.br
Internet: www.eppendorf.com.br

CANADA

Eppendorf Canada Ltd.
Tel. +1 905 826 5525
Fax +1 905 826 5424
E-Mail: canada@eppendorf.com
Internet: www.eppendorfna.com

CHINA

Eppendorf China Ltd.
Tel. +86 21 68760880
Fax +86 21 50815371
E-Mail: market.info@eppendorf.cn
Internet: www.eppendorf.cn

FRANCE

EPPENDORF FRANCE S.A.R.L.
Tel. +33 1 30 15 67 40
Fax +33 1 30 15 67 45
E-Mail: eppendorf@eppendorf.fr
Internet: www.eppendorf.fr

GERMANY

Eppendorf Vertrieb
Deutschland GmbH
Tel. +49 2232 418-0
Fax +49 2232 418-155
E-Mail: vertrieb@eppendorf.de
Internet: www.eppendorf.de

INDIA

Eppendorf India Limited
Tel. +91 44 42 11 13 14
Fax +91 44 42 18 74 05
E-Mail: info@eppendorf.co.in
Internet: www.eppendorf.co.in

ITALY

Eppendorf s.r.l.
Tel. +390 2 55 404 1
Fax +390 2 58 013 438
E-Mail: eppendorf@eppendorf.it
Internet: www.eppendorf.it

JAPAN

Eppendorf Co. Ltd.
Tel. +81 3 5825 2363
Fax +81 3 5825 2365
E-Mail: info@eppendorf.jp
Internet: www.eppendorf.jp

NORDIC

Eppendorf Nordic Aps
Tel. +45 70 22 29 70
Fax +45 45 76 73 70
E-Mail: nordic@eppendorf.dk
Internet: www.eppendorf.dk

SOUTH & SOUTHEAST ASIA

Eppendorf Asia Pacific Sdn. Bhd.
Tel. +60 3 8023 2769
Fax +60 3 8023 3720
E-Mail: asiapacifichq@eppendorf.com.my
Internet: www.eppendorf.com.my

SPAIN

Eppendorf Ibérica S.L.U.
Tel. +34 91 651 76 94
Fax +34 91 651 81 44
E-Mail: iberica@eppendorf.es
Internet: www.eppendorf.es

SWITZERLAND

Vaudaux-Eppendorf AG
Tel. +41 61 482 1414
Fax +41 61 482 1419
E-Mail: vaudaux@vaudaux.ch
Internet: www.eppendorf.ch

UNITED KINGDOM

Eppendorf UK Limited
Tel. +44 1223 200 440
Fax +44 1223 200 441
E-Mail: sales@eppendorf.co.uk
Internet: www.eppendorf.co.uk

USA

Eppendorf North America
Tel. +1 516 334 7500
Fax +1 516 334 7506
E-Mail: info@eppendorf.com
Internet: www.eppendorfna.com

OTHER COUNTRIES

Internet:
www.eppendorf.com/worldwide

eppendorf

In touch with life

Your local distributor: www.eppendorf.com/worldwide

Eppendorf AG · 22331 Hamburg · Germany · Tel. +49 40 538 01-0 · Fax +49 40 538 01-556 · E-Mail: eppendorf@eppendorf.com

Eppendorf North America, Inc. · One Cantiague Road · P.O. Box 1019 · Westbury, N.Y. 11590-0207 · USA
Tel. +1 516 334 7500 · Toll free phone 800 645 3050 · Fax +1 516 334 7506 · E-Mail: info@eppendorf.com

Application Support

Europe, International: Tel. +49 1803 666 789 · E-Mail: support@eppendorf.com
North America: Tel. 800 645 3050 ext. 2258 · E-Mail: support_NA@eppendorf.com
Asia, Pacific: Tel. +603 8023 2769 · E-Mail: support_AsiaPacific@eppendorf.com